

Unit E5 27-29 Fariola Street Silverwater NSW 2128 Ph: (02) 9647 3333 Fax: (02) 9647 3345

Web: www.nuteck.com.au ABN: 51 003 799 326

Panasonic Telephone - User Features

| Features | Method |
|-------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| 1. Answering Incoming Calls | Lift the hand piece (on ringing handsets) or simply Press the FLASHING RED line key |
| 2. Placing an Outside Call | Dial '0' then dial the external number(Unless advised not) |
| 3. Placing an internal call | Lift the hand piece then dial Extn No. |
| 4. Hands free - Microphone On / Off | Press SP-PHONE Press MUTE |
| 5. Transferring Calls | A) Press TRANSFER then dial Extn No, Announce Call – Hang Up B) For reception: Press DSS Button, Announce Call – Hang Up |
| 6. Last Number Redial | Press REDIAL |
| 7. Paging All | Lift Hand Piece & Dial * 3301 |
| 8. Speed Dial | System -lift hand piece - press AUTO DIAL/STORE then 3 digit speed dial code |
| 9. Background Music | ON: Speaker *7511 Speaker |
| | OFF: Speaker *7510 Speaker |
| 10. Extn Swap | Physically move the handset to new location. |
| | 2) At new location at current handset: Dial *# - EXTN – 1111 (Handset will reboot with desired extn number) |
| 11. Identifying your own extension | Press INFO key or Transfer Continue pressing to return to time view |

| Programming Features | |
|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Programming Extension Numbers | A) Under a DSS/one touch key PROGRAM(PROG) - BUTTON - DIAL 1 - EXTN NO - ENTER - ENTER NAME USING KEYPAD - AUTO DIAL/ STORE - lift hand piece and replace to exit programming |
| 2. Programming Telephone Numbers TRANSFER= CLEAR | A) Under DSS/ one touch key PROGRAM(PROG) - BUTTON - DIAL 2 - 0 - PHONE NUMBER - ENTER - ENTER NAME USING KEYPAD - AUTO DIAL/STORE - lift hand piece and replace to exit programming |
| 3. Conference Calls on desk telephones- 3 party conference inc. self | Get party no.1 on line (Outside Number or Internal Extension) Press CONF button Get party no.2 on line (Outside Number or Internal Extension) Press CONF and all 3 parties can converse with each other |

| Panasonic Conference Station | |
|---------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Internal Call | press speaker button - dial internal extension number |
| 2. External Call | press speaker button Dial '0' then dial the external number |
| 3. Conference Calls on conference station-3 party conference inc. self | Get party no.1 on line (Outside Number or Internal Extension) Press Recall button then wait for dial tone |
| | Get party no.2 on line (Outside Number or Internal Extension) Press Recall button then 3 on key pad - all parties can converse with each other |